

## Causation

## Blink Code

Over Voltage

The unit blinks 3 time at a minimal brightness and goes off until power cycle

Under Voltage

The unit blinks 4 times at a minimal brightness and goes off until power cycle

Over Current

The unit blinks 5 times at minimal brightness and goes off until power cycle

Under Current

The unit blinks 6 times at minimal brightness and goes off until power cycle